



Headrest Adjustment



Headrest Adjustment



Lumbar Adjustment

# LA VELLA user guide



Armpad Adjustment



Armpad Sliding



Tension Adjustment



Sliding Adjustment

Gaslift Adjustment



Locking Adjustment